



PIC 16F873A BOOTLOADER LOADED

- Working Principle
- Install the MPLAB IDE for Preparing programs
- Copy the Uploader folder to Desktop
- Execute the File Pic boot Plus file (exe file)
- Select the baud Rate – 56000 / Com port As per Your PC
- Open the Hex file from Search
- Click on Write - Reset the Bootloader Message
- Reset the Device Thru Reset SW

Configuration bits are standard – OCS –HS

